

BURNING

1. Place the pellet box so that it covers as well as possible
2. Fill in the box with the pellets to the upper edge. Add ½ decilitres of lighter fluid or lighter piece on the pellets
3. Fire the pellets and adjust the incoming air of the grate in an open position. Keep the air holes of the fireplace door closed.


The fire gets stronger as the pellets catch fire in 15 minutes time.

You can adjust the power of the flame by changing the incoming air of the grate.

Burning time is 1 hour depending of the strength of the flame and the amount of incoming air. The right strength of flame and incoming air must be tested case by case.

As the pellets have burned to a coal phase (blue flame) you can add incoming air to make the after-burning stronger.

DO NOT CLOSE THE SMOKE DAMPER UNTIL THE COALS HAVE EXTINGUISHED (DANGER OF CARBON MONOXIDE)!



ADDING PELLETS

As pellets have burned to red coals (2 cm level) you can add pellets in two different ways

1. Pull the rest of the red coals to the front of the box and add 2 litres of pellets to the backside of the coals so that the red coals are not covered OR
2. Add 1,5 litres of pellets on top of the red coals to the middle of the box so that it does not cover all of the red coals.

In this way you can keep burning for some time.

DO NOT ADD PELLETS ON TOP OF THE RED COALS BY COVERING THEM COMPLETELY! FIRING THE PELLETS TAKES A LONG TIME AND IT CREATES A LOT OF SMOKE!